

## ZO VOORKOM JE BRAND EN PANIEK

- Test de autonome rookmelder in je kamer, door de test knop in te drukken, de eerste donderdag van elke maand. Indien deze niet werkt vervang zo nodig de batterij en test opnieuw.
- Hou het gebouw ordelijk en net: rondslingerend materiaal veroorzaakt altijd een snelle uitbreiding van brand.
- Hou gangen, trappen, overlopen en nooduitgangen vrij.
- Hou (brand)deuren altijd gesloten en klem ze nooit open met een spie: in geval van brand gaan ze de verspreiding van rook en vuur tegen. Alleen deuren met een automatische sluiting bij brand mogen open blijven.
- Ga na waar zich de (nood)telefoon, de evacuatieknoppen en de blusmiddelen bevinden. Hou deze bereikbaar en gebruiksklaar. Bekijk de brandblussers op voorhand zodat je weet hoe ze werken.
- Verken de evacuatiewegen en (nood)uitgangen van je gebouw. Hou er rekening mee dat je een gang of trapzaal die met rook gevuld is, niet kan gebruiken. Indien de (nood)uitgangen bij brand niet meer te bereiken zijn, ga je best naar een kamer aan de straatkant om vanuit het raam om hulp te roepen. Kamers aan de straatkant zijn normaal gezien bereikbaar voor de brandweer.
- Wees voorzichtig met elektriciteit:
  - gebruik altijd materiaal met CE-keurmerk.
  - voorkom overbelasting van de kringen, sluit daarom slechts één toestel of contactdoos aan per muur-stopcontact.
  - gebruik geen apparaten met hoog verbruik, zoals elektrische vuurtjes of oven.
  - voorkom kortsluiting door stekkers, snoeren en apparaten niet te beschadigen.
  - leg nooit elektrische draden onder een tapijt of los over de vloer.
  - elektriciteit en vocht gaan niet samen: gebruik geen elektrische toestellen in de omgeving van wastafel of douche.

Bij vragen of problemen contacteer je verhuurder of verantwoordelijke.

## JE HOORT HET ALARM VAN EEN AUTONOME ROOKMELDER IN EEN KAMER



### 1 Bij accidentele activatie

Druk "stijl"-knop van de rookmelder in. Ventileer de kamer voldoende. Krijg je de rookmelder niet stil, verwittig dan de verhuurder of verantwoordelijke.



### 2 Alarm zonder zichtbare rook of vuur en kamer is op slot

Bonk op kamerdeur om eventuele slapende bewoner te wekken. Indien geen gehoor, verwittig de hulpdiensten (bel 112) en je verhuurder of verantwoordelijke en vraag om de kamer te openen. Blijf ter plaatse en blijf controleren op rook en vuur.

## JE ONTDEKT EEN BRAND



### 1 Sla alarm!

Roep: **BRAND! BRAND!** Hiermee waarschuw je de medebewoners en roep je extra hulp in.



### 2 Waarschuw de hulpdiensten (bel 112)

Zeg je naam, het adres, de verdieping, het kamernummer, de reden van je oproep.



### 3 Start de evacuatie

Geef een duidelijk signaal, druk op de evacuatieknop indien aanwezig.



### 4 Blus één poging

Gebruik een gepast blusmiddel. Giet NOOIT water op een brandende frituurketel!



### 5 Het vuur is geblust

Wacht ter plaatse op de hulpdiensten.



### 6 Het vuur is niet geblust

Verlaat ook onmiddellijk het gebouw.

## JE HOORT HET EVACUATIESIGNAAL: EVACUEER ONMIDDELIJK!



### 1 Verlaat je kamer

Sluit de ramen. Schakel elektrische toestellen uit. Laat de lichten branden. Neem jas, portefeuille, handtas en GSM mee. Doe je kamerdeur dicht.



### 2 Verlaat het gebouw

Gebruik de dichtstbijzijnde uitgang, eventueel de nooduitgang. Gebruik nooit de lift. Doe alle deuren, die je op je weg tegenkomt, dicht.



### 3 Begeef je naar de verzamelplaats

Dit is de parking, het voetpad aan de overkant van de straat of een grasveld, op een veilige afstand van het gebouw. Hou steeds de doorgang vrij voor de hulpdiensten. Wacht op de verzamelplaats op verdere instructies. Blijf ter beschikking van de hulpdiensten om de nodige informatie te verstrekken. Ga nooit het gebouw terug binnen!

## HOW TO AVOID FIRE AND PANIC

- Test the autonomous smoke detector by pressing the test button, every first Thursday of the month. In case it does not work replace the batteries if necessary and test again.
- Keep the building orderly and neat: scattered rubbish always causes the fire to spread rapidly. Keep corridors, stairways and emergency exits clear.
- Always keep (fireproof) doors shut and never jam them with a cotter. In the event of fire they will prevent flames and smoke from spreading through the building. Only doors closing automatically in case of fire may be left open.
- Check where the (emergency) telephones, the fire alarm buttons and the fire extinguishers are located. Keep them within reach and ready for use. Examine them in advance so you know how they work.
- Check out the escape routes and emergency exits in the house. Bear in mind that halls or stairways cannot be used when they are filled with smoke. Rooms located on the front side of the building can normally be attained from the street by the fire department. If, due to fire, emergency exits are no longer accessible, one should try to reach a room on the front side and call for help from the window.
- Be careful with electricity:
  - always use appliances with a CE-quality mark
  - prevent overloaded circuits, so never plug in more than one lamp or device per socket.
  - do not use too high-powered electrical appliances such as heating and cooking devices.
  - avoid short-circuits by keeping plugs, wires and appliances in order.
  - never put electrical wires under a carpet or loose over the floor.
  - electricity and humidity are not compatible: do not use electrical appliances near a washing table or shower.

If you have questions or problems contact your landlord or the person in charge.

## YOU HEAR THE ALARM OF AN AUTONOMOUS SMOKE DETECTOR IN A ROOM



### 1 In case of accidental activation

Press the 'silence' button of the detector. Properly ventilate the room. If you can not stop the smoke detector inform the landlord or the person in charge.



### 2 Alarm without visible smoke or fire and the room is locked

Bang the door of the room to wake up sleeping resident. In case there is no reaction, call the emergency services (call 112) and your landlord or the person in charge and ask him to open the door. Stay on the spot and continue to check for fire and smoke.

## YOU DISCOVER A FIRE



### 1 Sound the alarm!

Shout: **FIRE! FIRE!** By doing this you alert your co-tenants and call for extra help.



### 2 Call the emergency services (call 112)

Give your name, address, floor, room number and the motive of your call.



### 3 Start the evacuation

Give a clear signal, press the evacuation button if present.



### 4 Extinguish the fire: try once

Use an adequate fire extinguisher. NEVER throw water into a burning deep fryer.



### 5 If the fire is extinguished

Wait for the emergency services to arrive.



### 6 If the fire is not extinguished

Start to evacuate the building immediately.

## YOU HEAR THE FIRE ALARM: EVACUATE IMMEDIATELY!



### 1 Leave the room

Shut the windows. Switch off electrical appliances. Leave the lights on. Take your coat and wallet/bag/mobile with you. Close the door to your room.



### 2 Leave the building

Use the nearest exit, if necessary the emergency exit. Never use the elevator. Close every door on your way out.



### 3 Go to the gathering place

A parking lot, a footpath across the street or a lawn at a safe distance from the building. Keep the entrance clear for the emergency services. Wait on the gathering place for instructions. Stay around to provide the emergency services with the necessary information. Never enter the building again!